



RECOMMENDED MP3 PLAYER LIST

■ NO SD SLOT
 ■ HAS SD SLOT
 ■ FILE TRANSFER OPTION

<p>Greentouch Model: X5II</p> <p> <input checked="" type="checkbox"/> SD CARD <input checked="" type="checkbox"/> FILE TRANSFER <input checked="" type="checkbox"/> PICTURE-VIDEO <input checked="" type="checkbox"/> TOUCH </p> <p>Safety Level</p>	<p>Greentouch Model: Klip Player</p> <p> <input checked="" type="checkbox"/> SD CARD <input checked="" type="checkbox"/> FILE TRANSFER <input checked="" type="checkbox"/> PICTURE-VIDEO <input checked="" type="checkbox"/> TOUCH </p> <p>Safety Level</p>	<p>Greentouch Model: X3</p> <p> <input checked="" type="checkbox"/> SD CARD <input checked="" type="checkbox"/> FILE TRANSFER <input checked="" type="checkbox"/> PICTURE-VIDEO <input checked="" type="checkbox"/> TOUCH </p> <p>Safety Level</p>
<p>Greentouch Model: Plus Player</p> <p> <input checked="" type="checkbox"/> SD CARD <input checked="" type="checkbox"/> FILE TRANSFER <input checked="" type="checkbox"/> PICTURE-VIDEO <input checked="" type="checkbox"/> TOUCH </p> <p>Safety Level</p>	<p>Samvix Model: Dynamite 8 Gig</p> <p> <input checked="" type="checkbox"/> SD CARD <input checked="" type="checkbox"/> FILE TRANSFER <input checked="" type="checkbox"/> PICTURE-VIDEO <input checked="" type="checkbox"/> TOUCH </p> <p>Safety Level</p>	<p>Samvix Model: Dynamite 32/64/128 Gig</p> <p> <input checked="" type="checkbox"/> SD CARD <input checked="" type="checkbox"/> FILE TRANSFER <input checked="" type="checkbox"/> PICTURE-VIDEO <input checked="" type="checkbox"/> TOUCH </p> <p>Safety Level</p>
<p>Samvix Model: Dynamite</p> <p> <input checked="" type="checkbox"/> SD CARD <input checked="" type="checkbox"/> FILE TRANSFER <input checked="" type="checkbox"/> PICTURE-VIDEO <input checked="" type="checkbox"/> TOUCH </p> <p>Safety Level</p>	<p>Samvix Model: Glasba 4 & 8</p> <p> <input checked="" type="checkbox"/> SD CARD <input checked="" type="checkbox"/> FILE TRANSFER <input checked="" type="checkbox"/> PICTURE-VIDEO <input checked="" type="checkbox"/> TOUCH </p> <p>Safety Level</p>	<p>Samvix Model: iBusiness 32/128 Gig</p> <p> <input checked="" type="checkbox"/> SD CARD <input checked="" type="checkbox"/> FILE TRANSFER <input checked="" type="checkbox"/> PICTURE-VIDEO <input checked="" type="checkbox"/> TOUCH </p> <p>Safety Level</p>
<p>Samvix Model: Office Recorder</p> <p> <input checked="" type="checkbox"/> SD CARD <input checked="" type="checkbox"/> FILE TRANSFER <input checked="" type="checkbox"/> PICTURE-VIDEO <input checked="" type="checkbox"/> TOUCH </p> <p>Safety Level</p>	<p>Samvix Model: iBusiness plus</p> <p> <input checked="" type="checkbox"/> SD CARD <input checked="" type="checkbox"/> FILE TRANSFER <input checked="" type="checkbox"/> PICTURE-VIDEO <input checked="" type="checkbox"/> TOUCH </p> <p>Safety Level</p>	<p>Samvix Model: iBusiness plus 2.0</p> <p> <input checked="" type="checkbox"/> SD CARD <input checked="" type="checkbox"/> FILE TRANSFER <input checked="" type="checkbox"/> PICTURE-VIDEO <input checked="" type="checkbox"/> TOUCH </p> <p>Safety Level</p>
<p>Samvix Model: Glasba 64</p> <p> <input checked="" type="checkbox"/> SD CARD <input checked="" type="checkbox"/> FILE TRANSFER <input checked="" type="checkbox"/> PICTURE-VIDEO <input checked="" type="checkbox"/> TOUCH </p> <p>Safety Level</p>	<p>Samvix Model: iBass Touch</p> <p> <input checked="" type="checkbox"/> SD CARD <input checked="" type="checkbox"/> FILE TRANSFER <input checked="" type="checkbox"/> PICTURE-VIDEO <input checked="" type="checkbox"/> TOUCH </p> <p>Safety Level</p>	<p>Samvix Model: Cr 68 Recorder 64Gig</p> <p> <input checked="" type="checkbox"/> SD CARD <input checked="" type="checkbox"/> FILE TRANSFER <input checked="" type="checkbox"/> PICTURE-VIDEO <input checked="" type="checkbox"/> TOUCH </p> <p>Safety Level</p>

RECOMMENDED MP3 PLAYER LIST

■ NO SD SLOT
 ■ HAS SD SLOT
 ■ FILE TRANSFER OPTION

<p>Samvix Model: SmartBass 2.0</p> <p> <input checked="" type="checkbox"/> SD CARD <input checked="" type="checkbox"/> FILE TRANSFER <input checked="" type="checkbox"/> PICTURE-VIDEO <input checked="" type="checkbox"/> TOUCH </p> <p>■ Safety Level</p>	<p>Samvix Model: SmartBass 3.0</p> <p> <input checked="" type="checkbox"/> SD CARD <input checked="" type="checkbox"/> FILE TRANSFER <input checked="" type="checkbox"/> PICTURE-VIDEO <input checked="" type="checkbox"/> TOUCH </p> <p>■ Safety Level</p>	<p>Samvix Model: SmartBass 4.0</p> <p> <input checked="" type="checkbox"/> SD CARD <input checked="" type="checkbox"/> FILE TRANSFER <input checked="" type="checkbox"/> PICTURE-VIDEO <input checked="" type="checkbox"/> TOUCH </p> <p>■ Safety Level</p>
<p>Samvix Model: SmartBass Mini</p> <p> <input checked="" type="checkbox"/> SD CARD <input checked="" type="checkbox"/> FILE TRANSFER <input checked="" type="checkbox"/> PICTURE-VIDEO <input checked="" type="checkbox"/> TOUCH </p> <p>■ Safety Level</p>	<p>Samvix Model: SmartBass 128</p> <p> <input checked="" type="checkbox"/> SD CARD <input checked="" type="checkbox"/> FILE TRANSFER <input checked="" type="checkbox"/> PICTURE-VIDEO <input checked="" type="checkbox"/> TOUCH </p> <p>■ Safety Level</p>	<p>Samvix Model: SmartBass Tiny</p> <p> <input checked="" type="checkbox"/> SD CARD <input checked="" type="checkbox"/> FILE TRANSFER <input checked="" type="checkbox"/> PICTURE-VIDEO <input checked="" type="checkbox"/> TOUCH </p> <p>■ Safety Level</p>
<p>Akito Model: L4</p> <p> <input checked="" type="checkbox"/> SD CARD <input checked="" type="checkbox"/> FILE TRANSFER <input checked="" type="checkbox"/> PICTURE-VIDEO <input checked="" type="checkbox"/> TOUCH </p> <p>■ Safety Level</p>	<p>Sandisk Model: Clip voice</p> <p> <input checked="" type="checkbox"/> SD CARD <input checked="" type="checkbox"/> FILE TRANSFER <input checked="" type="checkbox"/> PICTURE-VIDEO <input checked="" type="checkbox"/> TOUCH </p> <p>■ Safety Level</p>	<p>Sony Model: Voice Recorder</p> <p> <input checked="" type="checkbox"/> SD CARD <input checked="" type="checkbox"/> FILE TRANSFER <input checked="" type="checkbox"/> PICTURE-VIDEO ↪ USUALLY IN A LIMITED WAY </p> <p>■ Safety Level</p>
<p>Akito Model: L5</p> <p> <input checked="" type="checkbox"/> SD CARD <input checked="" type="checkbox"/> FILE TRANSFER <input checked="" type="checkbox"/> PICTURE-VIDEO <input checked="" type="checkbox"/> TOUCH </p> <p>■ Safety Level</p>	<p>Akito Model: S7</p> <p> <input checked="" type="checkbox"/> SD CARD <input checked="" type="checkbox"/> FILE TRANSFER <input checked="" type="checkbox"/> PICTURE-VIDEO <input checked="" type="checkbox"/> TOUCH </p> <p>■ Safety Level</p>	<p>Akito Model: S8</p> <p> <input checked="" type="checkbox"/> SD CARD <input checked="" type="checkbox"/> FILE TRANSFER <input checked="" type="checkbox"/> PICTURE-VIDEO <input checked="" type="checkbox"/> TOUCH </p> <p>■ Safety Level</p>
<p>Olympus Model: Voice Recorder</p> <p> <input checked="" type="checkbox"/> SD CARD <input checked="" type="checkbox"/> FILE TRANSFER <input checked="" type="checkbox"/> PICTURE-VIDEO <input checked="" type="checkbox"/> TOUCH </p> <p>■ Safety Level</p>		

- Most Sandisk devices do not have picture or video. The radio can be removed by TAG.
- SD card slots can usually be removed by TAG.
- Generally, all wearable technology smartwatches are NOT safe.
- Any Devices running android are not recommended at all, and is NOT safe.
- TAG can remove radio from most devices, however picture or video viewer can never be removed.
- Be advised that many devices even with a Kosher label might have radio, picture viewer or video.