



RECOMMENDED MP3 PLAYER LIST

■ NO SD SLOT
 ■ HAS SD SLOT
 ■ COPY/PASTE OPTION

<p>Greentouch Model: X5II</p> <p> <input checked="" type="checkbox"/> SD CARD <input checked="" type="checkbox"/> COPY/PASTE <input checked="" type="checkbox"/> PICTURE-VIDEO <input checked="" type="checkbox"/> TOUCH </p> <p>Safety Level</p> <p>ALSO AVAILABLE WITHOUT SD SLOT</p>	<p>Greentouch Model: Six Player</p> <p> <input checked="" type="checkbox"/> SD CARD <input checked="" type="checkbox"/> COPY/PASTE <input checked="" type="checkbox"/> PICTURE-VIDEO <input checked="" type="checkbox"/> TOUCH </p> <p>Safety Level</p> <p>ALSO AVAILABLE WITHOUT SD SLOT</p>	<p>Greentouch Model: X3</p> <p> <input checked="" type="checkbox"/> SD CARD <input checked="" type="checkbox"/> COPY/PASTE <input checked="" type="checkbox"/> PICTURE-VIDEO <input checked="" type="checkbox"/> TOUCH </p> <p>Safety Level</p> <p>ALSO AVAILABLE WITHOUT SD SLOT</p>
<p>Greentouch Model: Plus Player</p> <p> <input checked="" type="checkbox"/> SD CARD <input checked="" type="checkbox"/> COPY/PASTE <input checked="" type="checkbox"/> PICTURE-VIDEO <input checked="" type="checkbox"/> TOUCH </p> <p>Safety Level</p> <p>ALSO AVAILABLE WITHOUT SD SLOT</p>	<p>Zymroo Model: ZYM 8.0</p> <p> <input checked="" type="checkbox"/> SD CARD <input checked="" type="checkbox"/> COPY/PASTE <input checked="" type="checkbox"/> PICTURE-VIDEO <input checked="" type="checkbox"/> TOUCH </p> <p>Safety Level</p>	<p>Samvix Model: HighClass</p> <p> <input checked="" type="checkbox"/> SD CARD <input checked="" type="checkbox"/> COPY/PASTE <input checked="" type="checkbox"/> PICTURE-VIDEO <input checked="" type="checkbox"/> TOUCH </p> <p>Safety Level</p>
<p>Samvix Model: Dynamite</p> <p> <input checked="" type="checkbox"/> SD CARD <input checked="" type="checkbox"/> COPY/PASTE <input checked="" type="checkbox"/> PICTURE-VIDEO <input checked="" type="checkbox"/> TOUCH </p> <p>Safety Level</p> <p>ALSO AVAILABLE WITHOUT SD SLOT</p>	<p>Samvix Model: Glasba 4 & 8</p> <p> <input checked="" type="checkbox"/> SD CARD <input checked="" type="checkbox"/> COPY/PASTE <input checked="" type="checkbox"/> PICTURE-VIDEO <input checked="" type="checkbox"/> TOUCH </p> <p>Safety Level</p>	<p>Samvix Model: iBusiness</p> <p> <input checked="" type="checkbox"/> SD CARD <input checked="" type="checkbox"/> COPY/PASTE <input checked="" type="checkbox"/> PICTURE-VIDEO <input checked="" type="checkbox"/> TOUCH </p> <p>Safety Level</p>
<p>Samvix Model: Office Recorder</p> <p> <input checked="" type="checkbox"/> SD CARD <input checked="" type="checkbox"/> COPY/PASTE <input checked="" type="checkbox"/> PICTURE-VIDEO <input checked="" type="checkbox"/> TOUCH </p> <p>Safety Level</p>	<p>Samvix Model: iBusiness plus</p> <p> <input checked="" type="checkbox"/> SD CARD <input checked="" type="checkbox"/> COPY/PASTE <input checked="" type="checkbox"/> PICTURE-VIDEO <input checked="" type="checkbox"/> TOUCH </p> <p>Safety Level</p>	<p>Samvix Model: iBusiness plus 2.0</p> <p> <input checked="" type="checkbox"/> SD CARD <input checked="" type="checkbox"/> COPY/PASTE <input checked="" type="checkbox"/> PICTURE-VIDEO <input checked="" type="checkbox"/> TOUCH </p> <p>Safety Level</p>
<p>Samvix Model: Glasba 64</p> <p> <input checked="" type="checkbox"/> SD CARD <input checked="" type="checkbox"/> COPY/PASTE <input checked="" type="checkbox"/> PICTURE-VIDEO <input checked="" type="checkbox"/> TOUCH </p> <p>Safety Level</p>	<p>Samvix Model: iBass Touch</p> <p> <input checked="" type="checkbox"/> SD CARD <input checked="" type="checkbox"/> COPY/PASTE <input checked="" type="checkbox"/> PICTURE-VIDEO <input checked="" type="checkbox"/> TOUCH </p> <p>Safety Level</p>	<p>Samvix Model: Cr 68 Recorder 64Gig</p> <p> <input checked="" type="checkbox"/> SD CARD <input checked="" type="checkbox"/> COPY/PASTE <input checked="" type="checkbox"/> PICTURE-VIDEO <input checked="" type="checkbox"/> TOUCH </p> <p>Safety Level</p>

RECOMMENDED MP3 PLAYER LIST

NO SD SLOT
 HAS SD SLOT
 COPY/PASTE OPTION

<p>Samvix Model: SmartBass 2.0</p> <p> <input checked="" type="checkbox"/> SD CARD <input checked="" type="checkbox"/> COPY/PASTE <input checked="" type="checkbox"/> PICTURE-VIDEO <input checked="" type="checkbox"/> TOUCH </p> <p>Safety Level</p>	<p>Samvix Model: SmartBass 4.0</p> <p> <input checked="" type="checkbox"/> SD CARD <input checked="" type="checkbox"/> COPY/PASTE <input checked="" type="checkbox"/> PICTURE-VIDEO <input checked="" type="checkbox"/> TOUCH </p> <p>Safety Level</p>	<p>Samvix Model: SmartBass 7.0</p> <p> <input checked="" type="checkbox"/> SD CARD <input checked="" type="checkbox"/> COPY/PASTE <input checked="" type="checkbox"/> PICTURE-VIDEO <input checked="" type="checkbox"/> TOUCH </p> <p>Safety Level</p>
<p>Samvix Model: SmartBass Mini</p> <p> <input checked="" type="checkbox"/> SD CARD <input checked="" type="checkbox"/> COPY/PASTE <input checked="" type="checkbox"/> PICTURE-VIDEO <input checked="" type="checkbox"/> TOUCH </p> <p>Safety Level</p> <p>ALSO AVAILABLE WITHOUT SD SLOT</p>	<p>Samvix Model: SmartBass Pro</p> <p> <input checked="" type="checkbox"/> SD CARD <input checked="" type="checkbox"/> COPY/PASTE <input checked="" type="checkbox"/> PICTURE-VIDEO <input checked="" type="checkbox"/> TOUCH </p> <p>Safety Level</p> <p>ALSO AVAILABLE WITHOUT SD SLOT</p>	<p>Samvix Model: SmartBass Tiny 2.0</p> <p> <input checked="" type="checkbox"/> SD CARD <input checked="" type="checkbox"/> COPY/PASTE <input checked="" type="checkbox"/> PICTURE-VIDEO <input checked="" type="checkbox"/> TOUCH </p> <p>Safety Level</p>
<p>Akito Model: L4</p> <p> <input checked="" type="checkbox"/> SD CARD <input checked="" type="checkbox"/> COPY/PASTE <input checked="" type="checkbox"/> PICTURE-VIDEO <input checked="" type="checkbox"/> TOUCH </p> <p>Safety Level</p>	<p>Sandisk Model: Clip voice</p> <p> <input checked="" type="checkbox"/> SD CARD <input checked="" type="checkbox"/> COPY/PASTE <input checked="" type="checkbox"/> PICTURE-VIDEO <input checked="" type="checkbox"/> TOUCH </p> <p>Safety Level</p>	<p>Sony Model: Voice Recorder</p> <p> <input checked="" type="checkbox"/> SD CARD <input checked="" type="checkbox"/> COPY/PASTE <input checked="" type="checkbox"/> PICTURE-VIDEO <small>USUALLY IN A LIMITED WAY</small> </p> <p>Safety Level</p>
<p>Akito Model: L5</p> <p> <input checked="" type="checkbox"/> SD CARD <input checked="" type="checkbox"/> COPY/PASTE <input checked="" type="checkbox"/> PICTURE-VIDEO <input checked="" type="checkbox"/> TOUCH </p> <p>Safety Level</p>	<p>Akito Model: S7</p> <p> <input checked="" type="checkbox"/> SD CARD <input checked="" type="checkbox"/> COPY/PASTE <input checked="" type="checkbox"/> PICTURE-VIDEO <input checked="" type="checkbox"/> TOUCH </p> <p>Safety Level</p>	<p>Akito Model: S8</p> <p> <input checked="" type="checkbox"/> SD CARD <input checked="" type="checkbox"/> COPY/PASTE <input checked="" type="checkbox"/> PICTURE-VIDEO <input checked="" type="checkbox"/> TOUCH </p> <p>Safety Level</p>
<p>Olympus Model: Voice Recorder</p> <p> <input checked="" type="checkbox"/> SD CARD <input checked="" type="checkbox"/> COPY/PASTE <input checked="" type="checkbox"/> PICTURE-VIDEO <input checked="" type="checkbox"/> TOUCH </p> <p>Safety Level</p>	<ul style="list-style-type: none"> • Most Sandisk devices do not have picture or video. The radio can be removed by TAG. • SD card slots can usually be removed by TAG. • Generally, all wearable technology smartwatches are NOT safe. • Any Devices running android are not recommended at all, and is NOT safe. • TAG can remove radio from most devices, however picture or video viewer can never be removed. • Be advised that many devices even with a Kosher label might have radio, picture viewer or video. 	