



# CAMERA WI-FI & VIDEO REMOVAL

## WI-FI REMOVAL

Most Canon camera's can have the Wi-Fi removed. (without opening the Camera)

## VIDEO REMOVAL

The following camera's we have the option of removing the Video Recording & Player in addition to the Wi-Fi:



**IXUS 132**

**ELPH 170**

**SX 530**

**G7X**

**IXUS 135**

**ELPH 180**

**SX 600**

**G7 X Mark II**

**IXUS 145**

**ELPH 190**

**SX 610**

**G7 X Mark III**

**IXUS 175**

**ELPH 200**

**SX 620**

**G9X**

**IXUS 180**

**ELPH 350**

**SX 700**

**G9 X Mark II**

**IXUS 185**

**ELPH 360**

**SX 710**

**G15**

**IXUS 190**

**S120**

**SX 720**

**G16**

**IXUS 285**

**SX 70**

**SX 730**

**EOS 250D**

**ELPH 115**

**SX 240**

**SX 740**

**EOS M200**

**ELPH 135**

**SX 260**

**G1X Mark II**

**ELPH 160**

**SX 280**

**G5X**

MORE MODELS WILL BE AVAILABLE SOON.